

P H I L I P

RUB ON TRANSFER APPLICATION

To apply a rub-on transfer, first, carefully position the design on your desired surface, then firmly rub the transfer using a tool like a popsicle stick or burnishing tool to ensure the design adheres properly; slowly peel away the transparent sheet to reveal the transferred image, re-applying pressure to any areas that might not be fully transferred.

K U B I C K I