

PHILIP KUBICKI

SWITCH STOP WASHER INSTALLATION

1. Make sure the switch is in the off position. (Turn switch control knob counterclockwise until it stops).
2. Uninstall the preamp from the bass.
3. Note the 12 round holes surrounding the threaded mounting shaft in the switch's face plate. One of these holes, located in either the 5 o'clock or 11 o'clock position, is filled so the stop washer prong cannot be installed into it. Install the washer with the prong going into the 5 or 11 o'clock position hole that is opposite the filled hole.
4. Apply a very small drop of super glue under the washer near the prong. Do not try to glue the entire surface contact area between the washer and the threaded switch shaft.
5. Install one of the preamp's mounting nuts onto the threaded switch shaft so it holds the washer firmly in place. Allow glue to dry for 30 minutes then remove mounting nut.
6. Reinstall preamp into the bass.